



WIRING USING STANDARD 5A CTs SHOWN.
 WHEN USING 5A CTs, ELKOR RECOMMENDS THE USE OF A SHORTING BLOCK.
 mV AND mA (MCT/MSCT) STYLE CTs TYPICALLY DO NOT REQUIRE THE USE OF
 A SHORTING BLOCK AS THEIR OUTPUTS DO NOT PRODUCE DANGEROUS
 VOLTAGE LEVELS.
 ALL CTs MUST BE MOUNTED ON RATED INSULATED CONDUCTORS.

ELKOR Technologies Inc.

DRAWN: PCK	TITLE: WattsOn-Mark II (2-element 3-wire, delta)	CODE:
CHECKED: CKK		
DATE: 2018/02/02	FILE: WattsOn - Wiring (3 wire delta).t4g	SHEET: 1 OF 1